

Ordering Information - 2166 UHF RFID Reader

2166 Reader Box Contents:



With 2D Barcode Imager, Order:

2166-ES1 (ETSI)

2166-AS1 (FCC)

Without Barcode Imager, Order:

2166-EX1 (ETSI)

2166-AX1 (FCC)

Please Note: Additional Items Required for Charging

A Docking Cradle, Power Supply Unit and IEC Line Cord (mains cable) are required in order to charge the 2166 Reader.

2166 Docking Cradle Box Contents:



Order:

1166-CRD-01-KIT

IEC Line Cords Available from TSL®:



For UK, order:
IEC-1M-UK



For EU, order:
IEC-1.8M-EU



For US, order:
IEC-1.8M-US